

SEHVX40BAW


SEHVX64BAW

NOTES to go through before starting the unit


X1M : Terminal
 X2M : Field wiring terminal for high voltage
 X3M : Field wiring terminal for low voltage (circuit 1)
 X4M : Factory wiring terminal for low voltage (circuit 2)

--- : Earth wiring
 --- : Field supply
 → **/12.2 : Connection ** continues on page 12 column 2
 ① : Several wiring possibilities


User installed options: ☐ EKRUHT* = Remote user interface
☐ 1 x EKRP1AHT* = Demand PCB's



POSITION IN SWITCH BOX



SYSTEM LAYOUT



SEHVX(40~64)BAW

LEGEND

Part n°	Description
A1P	Main PCB circuit 1
A2P	User interface PCB
A3P	Control PCB circuit 1
A4P	* Demand PCB
A5P	Main PCB circuit 2
A6P	* Demand PCB
A7P	* Remote user interface PCB
A8P	Control PCB circuit 2
C1 - C3	Filter capacitor
F1U (A*P)	Fuse (T, 3.15A 250V)
HAP (A*P)	PCB LED
K11E	Electronic expansion valve (Circuit 1)
K21E	Electronic expansion valve (Circuit 2)
K1P	Pump contactor
K1S	Pump overcurrent relay
K*R (A3P)	PCB relay
M1P	Pump
PS (A*P)	Switching power supply
Q1DI	# Earth leakage circuit breaker
R11T	Leaving water thermistor (Circuit 1)
R12T	Returning water thermistor (Circuit 1)
R13T	Refrigerant liquid thermistor (Circuit 1)
R14T	Refrigerant gas thermistor (Circuit 1)
R21T	Leaving water thermistor (Circuit 2)
R22T	Returning water thermistor (Circuit 2)
R23T	Refrigerant liquid thermistor (Circuit 2)
R24T	Refrigerant gas thermistor (Circuit 2)
S1L	Flow switch (Circuit 1)
S2L	Flow switch (Circuit 2)
S1S	# Thermostat input 1
S2S	# Thermostat input 2
S3S	# Operation ON input
S4S	# Operation OFF input
SS1 (A1P, A5P)	Selector switch (emergency)
SS1 (A2P)	Selector switch (main / sub)
SS1 (A7P)	* Selector switch (main / sub)
V1C - V2C	Ferrite core noise filter
X1M - X4M	Terminal strip
X801M (A*P)	* PCB terminal strip
Z1F - Z2F (A*P)	Noise filter

* : field installed option

: field supplied

4D112958