

RZQG125-140L(8)Y1

Indoor		Outdoor	Power supply	Voltage range	MCA	TOCA	MFA	MSC	RLA	kW	FLA	kW	FLA
FCQG125EVEB		RZQG125L8Y1B	3N~ 50Hz 380-415V	Minimum: 342 V Maximum 456 V	17,9	—	20	—	14,2	0,094+0,094	0,4+0,4	0,106	1,1
FCQHG125FVEB		RZQG125L8Y1B			18,3	—	20	—	14,2	0,094+0,094	0,4+0,4	0,244	1,4
FCQG35FVEB	x4	RZQG125L8Y1B			18,0	—	20	—	14,2	0,094+0,094	0,4+0,4	0,044x4	0,3x4
FCQG50FVEB	x3	RZQG125L8Y1B			17,6	—	20	—	14,2	0,094+0,094	0,4+0,4	0,039x3	0,3x3
FCQG60FVEB	x2	RZQG125L8Y1B			17,3	—	20	—	14,2	0,094+0,094	0,4+0,4	0,044x2	0,3x2
FCQG125FVEB		RZQG125L8Y1B			17,8	—	20	—	14,2	0,094+0,094	0,4+0,4	0,168	1
FFQ35C2VEB	x4	RZQG125L8Y1B			18,5	—	20	—	14,2	0,094+0,094	0,4+0,4	0,054x4	0,4x4
FFQ50C2VEB	x3	RZQG125L8Y1B			18,0	—	20	—	14,2	0,094+0,094	0,4+0,4	0,053x3	0,4x3
FFQ60C2VEB	x2	RZQG125L8Y1B			18,0	—	20	—	14,2	0,094+0,094	0,4+0,4	0,052x2	0,6x2
FDXS35F2VEB	x4	RZQG125L8Y1B			18,0	—	20	—	14,2	0,094+0,094	0,4+0,4	0,034x4	0,3x4
FDXS50F2VEB9	x3	RZQG125L8Y1B			18,4	—	20	—	14,2	0,094+0,094	0,4+0,4	0,063x3	0,5x3
FDXS60F2VEB	x2	RZQG125L8Y1B			17,8	—	20	—	14,2	0,094+0,094	0,4+0,4	0,060x2	0,5x2
FBQ35C8VEB	x4	RZQG125L8Y1B			22,5	—	25	—	14,2	0,094+0,094	0,4+0,4	0,140x4	1,2x4
FBQ50C8VEB	x3	RZQG125L8Y1B			21,0	—	25	—	14,2	0,094+0,094	0,4+0,4	0,140x3	1,2x3
FBQ60C8VEB	x2	RZQG125L8Y1B			19,3	—	20	—	14,2	0,094+0,094	0,4+0,4	0,350x2	1,1x2
FBQ125C8VEB		RZQG125L8Y1B			19,1	—	20	—	14,2	0,094+0,094	0,4+0,4	0,350	2,1
FDQ125C7VEB		RZQG125L8Y1B			19,1	—	20	—	14,2	0,094+0,094	0,4+0,4	0,350	2,1
FVQ125C2VEB		RZQG125L8Y1B			18,0	—	20	—	14,2	0,094+0,094	0,4+0,4	0,238	1,2
FHQ35CBVEB	x4	RZQG125L8Y1B			19,5	—	20	—	14,2	0,094+0,094	0,4+0,4	0,060x4	0,6x4
FHQ50CBVEB	x3	RZQG125L8Y1B			18,8	—	20	—	14,2	0,094+0,094	0,4+0,4	0,060x3	0,6x3
FHQ60CBVEB	x2	RZQG125L8Y1B			18,0	—	20	—	14,2	0,094+0,094	0,4+0,4	0,091x2	0,6x2
FHQ125CBVEB		RZQG125L8Y1B			18,4	—	20	—	14,2	0,094+0,094	0,4+0,4	0,150	1,5
FUQ125C2VEB		RZQG125L8Y1B			18,3	—	20	—	14,2	0,094+0,094	0,4+0,4	0,106	1,4
FCQG71FVEB	x2	RZQG140L7Y1B	3N~ 50Hz 380-415V	Minimum: 342 V Maximum 456 V	17,5	—	20	—	14,2	0,094+0,094	0,4+0,4	0,048x2	0,4x2
FCQHG140EVEB		RZQG140L7Y1B			17,9	—	20	—	14,2	0,094+0,094	0,4+0,4	0,106	1,1
FCQHG71FVEB	x2	RZQG140L7Y1B			17,8	—	20	—	14,2	0,094+0,094	0,4+0,4	0,091x2	0,5x2
FCQHG140FVEB		RZQG140L7Y1B			18,3	—	20	—	14,2	0,094+0,094	0,4+0,4	0,244	1,4
FCQG35FVEB	x4	RZQG140L7Y1B			18,0	—	20	—	14,2	0,094+0,094	0,4+0,4	0,044x4	0,3x4
FCQG50FVEB	x3	RZQG140L7Y1B			17,6	—	20	—	14,2	0,094+0,094	0,4+0,4	0,039x3	0,3x3
FCQG71FVEB	x2	RZQG140L7Y1B			17,5	—	20	—	14,2	0,094+0,094	0,4+0,4	0,054x2	0,4x2
FCQG140FVEB		RZQG140L7Y1B			17,8	—	20	—	14,2	0,094+0,094	0,4+0,4	0,168	1
FFQ35C2VEB	x4	RZQG140L7Y1B			18,5	—	20	—	14,2	0,094+0,094	0,4+0,4	0,052x4	0,4x4
FFQ50C2VEB	x3	RZQG140L7Y1B			18,0	—	20	—	14,2	0,094+0,094	0,4+0,4	0,053x3	0,4x3
FFQ50F2VEB9	x4	RZQG140L7Y1B			18,0	—	20	—	14,2	0,094+0,094	0,4+0,4	0,034x4	0,3x4
FDXS50F2VEB	x2	RZQG140L7Y1B			18,4	—	20	—	14,2	0,094+0,094	0,4+0,4	0,063x2	0,5x2
FBQ35C8VEB	x4	RZQG140L7Y1B			22,5	—	25	—	14,2	0,094+0,094	0,4+0,4	0,140x4	1,2x4
FBQ50C8VEB	x3	RZQG140L7Y1B			21,0	—	25	—	14,2	0,094+0,094	0,4+0,4	0,140x3	1,2x3
FBQ71C8VEB	x2	RZQG140L7Y1B			19,3	—	20	—	14,2	0,094+0,094	0,4+0,4	0,350x2	1,1x2
FBQ140C8VEB		RZQG140L7Y1B			19,1	—	20	—	14,2	0,094+0,094	0,4+0,4	0,350	2,1
FHQ140CBVEB		RZQG140L7Y1B			18,8	—	20	—	14,2	0,094+0,094	0,4+0,4	0,150	1,8
FUQ71C2VEB	x2	RZQG140L7Y1B			18,8	—	20	—	14,2	0,094+0,094	0,4+0,4	0,046x2	0,9x2

Symbols

MCA: Minimum Circuit Ampere [A]

TOCA: Total overcurrent amps [A]

MFA: Maximum Fuse Ampere [A]

MSC: Maximum current of the starting compressor [A]

RLA: Rated load amps [A]

OFM: Outdoor fan motor

IFM: Indoor fan motor

FLA: Full Load Ampere [A]

KW: Fan motor rated output [kW]

Notes

- The RLA is based on the following conditions.

Cooling

Indoor temperature 27.0°C DB / 19.0°C WB

Outdoor temperature 35.0°C DB

Heating

Indoor temperature 20.0°C DB

Outdoor temperature 7.0°C DB / 6.0°C WB

- TOCA is the total value of each overcurrent set.

- Voltage range

The units are suitable for use with electrical systems in which the voltage supplied to the unit terminals is not below or above the listed range limits.

- The maximum allowable voltage that is unbalanced between phases is 2%.

- MCA is the maximum input current.

The capacity of the MFA must be greater than that of the MCA.

Select the MFA according to the table.

- Select the wire size according to the MCA.

- MFA is used to select the circuit breaker and the ground fault circuit interruptor.

Earth leakage circuit breaker