



Model
SV1A25AJV1B
SV4A14AJV1B
SV6-8A14AJV1B

1. Leave sufficient space to connect the refrigerant piping.
2. Install in an area where a downward slope of $\cdot 1/100 \cdot$ or more is possible.