





NOTES :

1. INSTALLATION:

- MAKE SURE THAT THE EXPANSION VALVE KIT IS INSTALLED VERTICALLY.
- THE EXPANSION VALVE KIT CAN BE INSTALLED INSIDE OR OUTSIDE.
- DO NOT INSTALL THE EXPANSION VALVE KIT IN OR ON THE OUTDOOR UNIT.
- DO NOT PUT THE EXPANSION VALVE KIT IN DIRECT SUNLIGHT. DIRECT SUNLIGHT WILL INCREASE THE TEMPERATURE INSIDE THE EXPANSION VALVE KIT AND MAY REDUCE ITS LIFETIME AND INFLUENCE ITS OPERATION.
- CHOOSE A FLAT AND STRONG MOUNTING SURFACE.

2. SERVICE SPACE:

- KEEP THE SPACE FREE FOR FUTURE MAINTENANCE.



ITEM	PART NAME
1	4 HOLES TO FIX THE VALVE KIT
2	VALVE KIT BOX LID
3	LIQUID PIPING FROM OUTDOOR UNIT
4	LIQUID PIPING TO AIR HANDLING UNIT