

Machine type
EWA = Air-cooled chiller, cooling only
EWY = Air-cooled chiller, heat pump
EWL = Remote condenser chiller
ERA = Air cooled condensing unit
EWW = Water-cooled chiller, cooling only
EWC = Air-cooled chiller, cooling only with centrifugal fan
EWT = Air-cooled chiller, cooling only with heat recovery

Refrigerant
D = R-134a
P = R-407c
Q = R-410a

Capacity class in kW (Cooling)
Always 3-digit code
Idem as previous

Model series
Letter A, B,… : major modification

Inverter
- = Non-inverter
Z = Inverter

Efficiency level
S = Standard efficiency
X = High efficiency
P = Premium efficiency
H = High ambient

Sound level
S = Standard noise
L = Low noise
R = Reduced noise
X = Extra low noise
C = Cabinet

Warranty
0 = 1 year of warranty
B = 2 years of warranty
C = 3 years of warranty
... = ... years of warranty

Sequential number
000 = Base model
001 = First order for this model (1 or more units)
002 = Second order for this model (1 or more units)
... = ... order for this model
B01 = First order for this model + 1year warranty
B02 = Second order for this model (1 or more units)
... = ... order for this model