


## Unit without pump



1-size 016-021-025

2-size 032

3-size 040-050

4-size 064

4TW60719-3 (3)

**WARNING**

1. Selecting a flow outside the curves can cause damage to or malfunctioning of the unit.
2. See minimum and maximum allowed flow in the technical specifications.