

Machine type

EWA = Air-cooled chiller, Cooling only
EWY = Air-cooled chiller, Heat pump
EWL = Remote condenser chiller
ERA = Air Cooled Condensing Unit
EWW = Water-cooled chiller, Cooling only
EWC = Air-cooled chiller, cooling only with centrifugal fan
EWT = Air-cooled chiller, cooling only with heat recovery

Refrigerant

D = R-134a
P = R-407c
Q = R-410a

Capacity class in kW (Cooling)

Always 3-digit code
Idem as previous

Model series

Letter A, B, . . . : major modification

Inverter

- = Non inverter
Z = Inverter

Efficiency level

S = Standard Efficiency
X = High Efficiency (N.A. for this range)
P = Premium efficiency (N.A. for this range)

Sound level

S = Standard Noise
L = Low noise (N.A. for this range)
R = Reduced noise (N.A. for this range)
X = Extra low noise (N.A. for this range)
C = Cabinet (N.A. for this range)

Warranty

0 = 1 year of warranty
B = 2 years of warranty
C = 3 years of warranty
... = ... years of warranty

Sequential number

000 = Base model
001 = First order for this model (1 or more units)
002 = Second order for this model (1 or more units)
... = ...order for this model
B01 = First order for this model + 1 year of warranty
B02 = Second order for this model (1 or more units)
... = ...order for this model