

FWP-AT
Accessory table

Description	02	03	04	05	06	07
Additional heat exchanger	EAH04A6			EAH07A6		
3-way valve cooling h/e	factory mounted					
3-way valve add. h/e	E2MV307A6					
2-way valve cooling h/e	factory mounted					
2-way valve add. h/e	E2MV207A6					
Electric heater	factory mounted					
Controller - Advanced plus version	FWEC3A					
Temperature sensor kit	FWTSKA					
Relative humidity sensor kit	FWHСКА					
Wall mounting kit for controller	FWFCKA					