

SEHVX20BAW
SEHVX32BAW

LEGEND			
Part n°		Description	
A1P		Main PCB (master)	
A2P		User interface PCB	
A3P		Control PCB	
A4P	*	Demand PCB	
A5P		Main PCB (slave)	
A7P	*	Remote user interface PCB	
C1 - C3		Filter capacitor	
F1U (A*P)		Fuse (T, 3.15A 250V)	
HAP (A*P)		PCB LED	
K11E		Electronic expansion valve (Circuit 1)	
K1P		Pump contactor	
K1S		Pump overcurrent relay	
K*R (A3P)		PCB relay	
M1P		Pump	
PS (A*P)		Switching power supply	
Q1DI	#	Earth leakage circuit breaker	
R11T		Leaving water thermistor (Circuit 1)	
Part n°		Description	
R12T		Returning water thermistor (Circuit 1)	
R13T		Refrigerant liquid thermistor (Circuit 1)	
R14T		Refrigerant gas thermistor (Circuit 1)	
S1L		Flow switch (Circuit 1)	
S1S	#	Thermostat input 1	
S2S	#	Thermostat input 2	
S3S	#	Operation ON input	
S4S	#	Operation OFF input	
SS1 (A1P, A5P)		Selector switch (emergency)	
SS1 (A2P)		Selector switch (main / sub)	
SS1 (A7P)	*	Selector switch (main / sub)	
V1C - V2C		Ferrite core noise filter	
X1M - X4M		Terminal strip	
X801M (A*P)	*	PCB terminal strip	
Z1F - Z2F (A*P)		Noise filter	
* : field installed option			
# : field supplied			