


Legend



In case valve kit ·AFVALVE1· is part of the system, then the minimum setpoint is ·7·°C.



Pull-down area

Notes

1. For more information, refer to the installation manual.

If negative ambient temperatures are expected, both in operation or at standstill, take adequate countermeasures against freezing.