

Tabla 1	
Modelo	PIN -CN -> PIN -AT
FWH06AAT/FWH07AAF	GV(BK) -> 3; MV(BU) -> 5; PV(RD) -> 6
FWH08AAT	GV(BK) -> 1; MV(BU) -> 3; PV(RD) -> 5
FWH06AAF	GV(BK) -> 3; MV(BU) -> 4; PV(RD) -> 6
FWH08AAF	GV(BK) -> 1; MV(BU) -> 2; PV(RD) -> 5

Hilos eléctricos, 3 velocidades FWH-A 06-08 + válvula de ENCENDIDO/APAGADO

