


FWQ-A



Model	AA	AB	AC	AD
FWQ04A, FWQ05A	550	629	592	769
FWQ07A	700	779	742	919
FWQ09A, FWQ11A, FWQ14A	1060	1139	1102	1279
FWQ17A, FWQ20A, FWQ24A	1480	1559	1522	1699

Item	Name	Description	Remark
KA	Water pipe connection cooling in	3/4" BSP female	Water in for 2P/4P (cooling)
KB	Water pipe connection cooling out	3/4" BSP female	Water out for 2P/4P (cooling)
KC	Water pipe connection heating in	3/4" BSP female	Water in for 4P (heating)
KD	Water pipe connection heating out	3/4" BSP female	Water out for 4P (heating)
KE	Drain pipe connection	VP20 (O.D. Ø26)	
KF	Power supply connection		
KG	Air filter		
KH	Air purge		
KJ	Air purge		Only for FWQ-AAF models
KK	Drain pan socket		Only in case of drain pump not used
KL	Drain hose (accessory)	O.D. Ø32 male	

NOTES

1. Air filter (KG) is flexible.