

FWT05HT
FWT06HT

1	BOTTOM FRAME ASSY
2	DRAIN PAN ASSY
2.1	STEPPING MOTOR
3	MOTOR MOUNTING PLATE (1)
4	MOTOR MOUNTING PLATE (2)
5	FAN MOTOR (DC)
6	MOTOR MOUNTING PLATE (3)
7	CROSS FLOW FAN ASSY
8	FAN BEARING VIBRATION ABSORBER ASSY (M)
9	HEAT EXCHANGER ASSY
9.1	RIGHT SIDE PANEL(RESIN)
10	DRAIN HOSE ASSY
11	INSTALLATION PLATE ASSY
12	EL.COMPO.ASSY
12.1	CONTROL MODULE
12.2	INDOOR COIL SENSOR
12.3	PRINTED CIRCUIT BOARD ASSY (DISPLAY)
12.4	ASSY, HARNESS WIRE
12.5	TERMINAL BLOCK
13	SHIELD PLATE(2)
14	DRAIN PAN ASSY (RESIN) EXTENSION
15	FRONT GRILLE ASSY
15.1	FRONT PANEL
16	DISCH.GRILLE HOR.BLADE (1) ASSY
17	DISCH.GRILLE HOR.BLADE (2) ASSY
18	AIR FILTER
19	SERVICE COVER ASSY
20	SEALING PLATE (TOP)
21	AIR FILTER PM2.5
22	LEFT SIDE PANEL (RESIN)
23	COVER ASSY, STREAMER (HOLDER)
23.1	DISCHARGE PLATE STREAMER ASSY

