

**FWT02HTV**  
**FWT03HTV**  
**FWT04HTV**

NO	DESCRIPTION
1	BOTTOM FRAME ASSY
2	DRAIN PAN ASSY
2.1	STEPPING MOTOR
3	MOTOR MOUNTING PLATE (1)
4	MOTOR MOUNTING PLATE (2)
5	FAN MOTOR (DC)
6	MOTOR MOUNTING PLATE (3)
7	CROSS FLOW FAN ASSY
8	FAN BEARING VIBRATION ABSORBER ASSY (M)
9	RIGHT SIDE PANEL (RESIN)
10	HEAT EXCHANGER ASSY
10.1	MOTOR OPERATED VALVE BODY (1770853)
11	DRAIN HOSE ASSY
12	INSTALLATION PLATE ASSY
13	EL.COMPO.ASSY
13.1	CONTROL MODULE
13.2	INDOOR COIL SENSOR
13.3	PRINTED CIRCUIT BOARD ASSY (DISPLAY)
13.4	ASSY, HARNESS WIRE
13.5	TERMINAL BLOCK
14	SHIELD PLATE(2)
15	DRAIN PAN ASSY (RESIN) EXTENSION
16	FRONT GRILLE ASSY
16.1	FRONT PANEL
17	DISCH.GRILLE HOR.BLADE ASSY
18	AIR FILTER
19	SERVICE COVER ASSY
20	SEALING PLATE (TOP)
21	AIR FILTER PM2.5
22	SIDE PANEL (LEFT)
23	COVER ASSY, STREAMER (HOLDER)
23.1	DISCHARGE PLATE STREAMER ASSY
24	WIRE HARNESS ASSY (ACTUATOR WIRE)
25	REDUCING SOCKET ADAPTOR

