
EHVH-DV

① Space heating - water OUT
② Space heating - water IN
③ Domestic hot water: hot water out
④ Domestic hot water: cold water in
⑤ Shut-off valve
⑥ Expansion vessel
⑦ Magnetic filter / dirt separator
⑧ Safety valve
⑨ Air purge
⑩ Drain valve
⑪ Pump
⑫ Plate heat exchanger
⑬ Refrigerant pressure sensor
⑭ Space heating water pressure sensor
⑮ Flow sensor
⑯ 3-way valve (space heating/domestic hot water)
⑰ R1T – Outlet water heat exchanger thermistor
⑱ R3T – Thermistor (heat exchanger, liquid pipe)
⑲ R4T – Inlet water thermistor
⑳ R5T – Tank thermistor
㉑ R8T – Tank thermistor

Screw connection	Brazed connection
Quick coupling	Flare connection



3D111712