EDLA04-08EV3 EBLA04-08E3V3 EDLA04-08E3V3 318.7 Without Backup heater Backup heater (12)1245.4 (15) (15) (10) 3 2 _210. 1 4 5 6 Water in connection ⋅1"M⋅ Water out connection ·1"M· (18)Wiring intake (low voltage wiring) 157 Wiring intake (high voltage wiring) Wiring intake (power supply) Backup heater power supply Shut-off valve / filter (included accessory) 8 Drain valve water circuit 9 Flow sensor 161.2 877 10 Expansion vessel 11 Backup heater 12 Automatic air purge valve (18) (17)(16) (18) (17)(16) (13) Space heating water pressure sensor 14 Safety valve 15 Pump 16 Drain outlet 17) 4 holes for anchor bolts (18) Mounting foot

EBLA04-08EV3