






**EABH-D6V**  
**EABH-D9W**  
**EABX-D6V**  
**EABX-D9W**



- ① Space heating - water OUT
- Field piping connections
- ② Water in connection ·1"·
- ③ Shut-off valve ·1"· (male-female)
- ④ Magnetic filter / dirt separator
- ⑤ Safety valve
- ⑥ Air purge
- ⑦ Drain valve
- ⑧ Flow sensor
- ⑨ Flow switch
- ⑩ Expansion vessel
- ⑪ Backup heater
- ⑫ Pump
- ⑬ Space heating water pressure sensor
- ⑭ R1T - Inlet water thermistor
- ⑮ R2T - Outlet water backup heater thermistor
- ⑯ Screw connection ·1"·

 Screw connection	 Brazed connection
 Quick coupling	 Flare connection