


**EBHQ-BB6V3**



Notes  
I: High speed  
II: Medium speed

ESP: External Static Pressure  
Flow: water flow through the unit

Warning  
1. Selecting a flow outside the operating area can damage the unit or cause the unit to malfunction. See also the minimum and maximum allowed water flow range in the technical specifications.  
2. Water quality must be according to EU directive 98/83 EC.