


EHBH-E6V / EHBH-E9W / EHBX-E6V / EHBX-E9W  
 ESHH-E / ESHB-E / EHSX-E / EHSXB-E  
 EHVH-E6V / EHVH-E6VG / EHVH-E9W / EHVX-E3V / EHVX-E6V / EHVX-E9W / EHVZ-E6V / EHVZ-E9W



Legend

[Shaded Box] Booster heater only operation (if a booster heater is part of the system)

- (1) ·EHVH\*S\*CBV· indoor units only
- (2) Combination of ·EKHWS(P)1\*DA\*· and ·EHB\*D/E(A/F)V\*· indoor units
- (3) Combination of ·EKHWS(P)(2/3)\*DA\*· and ·EHB\*D/E(A/F)V\*· indoor units

(\*) System operation: the system consists of an outdoor unit and indoor unit, and depending on the system, a booster heater and/or a backup heater.

Remark

In restricted power supply mode (·EKHW\*· only ), the outdoor unit, booster heater and backup heater can only operate separately.

If the outdoor temperature ·<-20·°C, then outdoor unit operation is possible, but with a possible capacity reduction.

If the outdoor temperature < -25°C, the outdoor unit will stop.

Indoor unit and backup heater operation will continue.