

EHBH-CBV

1 Phase + 3 Phase C Series
3 Phase B Series
11~16kW Class

Backup heater





Legend

- Backup heater only operation
  No outdoor unit operation
- Operation of outdoor unit possible, but with possible capacity reduction. If the outdoor temperature < -25°C, the outdoor unit will stop. Indoor unit and backup heater operation will continue.
- Outdoor unit operation if setpoint ≥ 25°C
- Circulation pump
- Outdoor unit operation + backup heater operation

Remark

In restricted power supply mode, the outdoor unit, anti-legionella heater and backup heater can only operate seperatly.

(*) units include special equipment (insulation, heater sheet, …) to ensure good operation in areas where low ambient temperature can occur together with high humidity conditions.
In such conditions the *RLQ models may experience problems with severe ice build up on the aircooled coil.
In case such conditions are expected, the *RLQ must be installed instead.
These models contain countermeasures (insulation, heater sheet, …) to prevent freeze up.