

Factory-mounted equipment for -EHS(H/X)(B/-)(04/08)P*E*.

Description	EHS(H/X)*(04/08)P30E*	EHS(H/X)*(04/08)P50E*
Domestic hot water tank -300l integrated-	o	-
Domestic hot water tank -500l integrated-	-	o

Outdoor combination table for -EHS(H/X)(B/-)(04/08)P*E*.

		ERGA04EAV3*	ERGA06EAV3*	ERGA08EAV3*
EHSH04P(30/50)E*	Heating only indoor unit, Std	o	-	-
EHSHB04P(30/50)E*	Heating only indoor unit, bivalent	o	-	-
EHSH08P(30/50)E*	Heating only indoor unit, Std	-	o	o
EHSHB08P(30/50)E*	Heating only indoor unit, bivalent	-	o	o
EHSX04P(30/50)E*	Reversible indoor unit, Std	o	-	-
EHSXB04P(30/50)E*	Reversible indoor unit, bivalent	o	-	-
EHSX08P(30/50)E*	Reversible indoor unit, Std	-	o	o
EHSXB08P(30/50)E*	Reversible indoor unit, bivalent	-	o	o

Kit availability for indoor units

Reference	Description	EHS*(04/08)P(30/50)E*	EHS*B(04/08)P(30/50)E*
EKECBUAF3V	Inline backup heater 3kW *(16)	Mandatory	o *(17)
EKECBUAF6V	Inline backup heater 6kW *(16)	Mandatory	o *(17)
EKECBUAF9W	Inline backup heater 9kW *(16)	Mandatory	o *(17)
EKECBUC03AF	Inline BUH connection kit BML	Mandatory	o *(17)
EKRP1HBAA	Digital I/O PCB	*(1) (2)	-
EKRP1AHTA	Demand PCB	*(3)	o
BRC1HHDA*	HCI (Human Comfort Interface)		o
EKPCCA84	PC cable	*(4)	o
KRCS01-1	Remote indoor sensor	*(5)	o
EKRSCA1	Remote sensor for outdoor	*(5)	o
EKCC8-W	Universal centralised user interface		o
DCOM-LT/IO	DCOM gateway	-	-
DCOM-LT/MB	DCOM gateway	-	-
EKCC8-W	Cascade control		o
EKHVC0NV4	Conversion kit: heating only to reversible.	-	-
FWXV10-15-20ATV3	Heat pump convector	*(6)	o
FWXT10-15-20ATV3	Heat pump convector	*(6)	o
FWXM10-15-20ATV3	Heat pump convector	*(6)	o
EKVKHPC	Heat pump convector valve kit	-	-
EKRRTWA	Wired room thermostat		o
EKRTR1, EKTRTB	Wireless room thermostat		o
EKRTE1S	External sensor room thermostat	*(7)	o
EKWUFHTA1V3	Multi-zoning base unit 230 V	*(9)	o
EKWCTRD1V3	Digital thermostat 230 V	*(9)	-
EKWCTRAN1V3	Analogue thermostat 230 V	*(9)	-
EKWCVATR1V3	Actuator 230 V	*(9)	-
EKRELSG	Relay for Smart Grid		o
BRP069A61	LAN adapter with solar connectivity		o
BRP069A62	LAN adapter		o
BRP069A71	WLAN module	*(10)	o
EKUHWG3D	-G3- kit	*(11)	-
AFVALVE1	Freeze protection valve	-	-
ESAE04A01*	Daikin Residential Controller	-	-
156021	dirt seperator		o
EKECBIVC02AF	Biv Connector Kit		o
EKECDBC02AF	DB connector Kit		o
EKSRRPS4A8	Drain back solar control pump station		o

Reference	Description	
		EHS*(04/08)P(30/50)E*
EKMIKPOAF	Mixing kit – PCB only	o
EKMIKPHAF	Mixing kit – PCB with hydraulics	o
EKMIKHMAF	Hydraulics – mixed pump group	*(12) o
EKMIKHUAF	Hydraulics – unmixed pump group	*(12) o
EKMIKBVAF	Balancing vessel	o
EKMIKDIAF	Distributor for balancing vessel	*(13) o

Notes

- (1) PCB that provides additional output connections: - -

(a) Control external heat source (bivalent operation).

(b) Output remote ON/OFF signal space heating/cooling

(c) Remote alarm output
- (2) Additional relays to allow bivalent control in combination with an external room thermostat are field-supplied.
- (3) PCB to receive up to -4- digital inputs for power limitation
- (4) Data cable for connection with PC.
- (5) Only 1 remote sensor can be connected: indoor OR outdoor sensor.
- (6) The valve kit is mandatory if a heat pump convector is installed on a reversible model (not mandatory for heating only models).
- (7) -EKRTETS- can only be used in combination with -EKTRT1-
- (8) The backup heater capacity depends on a user interface setting.
- (9) Multi-zoning wired controls
- (10) The WLAN cartridge is supplied in the accessory bag of the unit and is meant to be plugged into the SD card slot on the MMI-2.

In case of bad signal reception, the WLAN cartridge can be removed and replaced by the WLAN module.
- (11) This kit is mandatory for the UK models.
- (12) Only possible in combination with -EKMIKPOAF-
- (13) Only possible in combination with -EKMIKBVAF- and -EKMIKPHAF- or -EKMIKHUAF-
- (14) Only possible in combination with -HBKIT*.
- (15) Only possible in combination with -ETVZ*.
- (16) Only 1 Backup heater can be connected on one unit: 3 or 6* or 9 kW (*No 6T1-model applicable). EKECBUC0*AF is needed to connect the backup heater to the main unit
- (17) Mandatory for installations without a bivalent heat source (oil or gas)

Remark

Other combinations than mentioned in this combination table are prohibited.