

EHVH-E6V / EHVH-E9W / EHVH-E3V / EHVX-E6V / EHVX-E6VG / EHVX-E9W / EHVZ-E9W

Factory-mounted equipment for -EHV(H/X/Z)04S*E(A/J)*-

Description	EHV(H/X/Z)04S*E(A/J)*			
Heating only model -EHVH*-		18 - 6V (9)		23 - 6V (9)
Reversible model -EHVX*-	18 - 3V	18 - 6V (9)	23 - 3V	23 - 6V (9)
(Integrated Bizone)		18 - 6V (9)		
Heating only indoor unit for the UK		18 - 6V (9)		23 - 6V (9)
Backup heater -3kW 1N~230 V-	0	-	0	-
Backup heater -2-4-6kW 1N~230 V-	-	0	-	0
Backup heater -2-4-6kW 3~230 V-	-	0	-	0
Backup heater -3-6-9kW 3N~400 V-	-	-	-	-
Domestic hot water tank -180L-	0	0	-	-
Domestic hot water tank -230L-	-	-	0	0

Outdoor combination table for -EHV(H/X/Z)(04/08)S(U)(18/23)E(A/J)*-

		ERGA04EAV3	ERGA06EAV3	ERGA08EAV3	ERGA04EAV3A	ERGA06EAV3A	ERGA08EAV3A
EHVH04S(18/23)E(A/J)*	Heating only indoor unit	0	---	---	0	---	---
EHVX04S(18/23)E(A/J)*	Reversible indoor unit	0	---	---	0	---	---
EHVZ04S(18/23)E(A/J)*	(Integrated Bizone)	0	---	---	---	---	---
EHVH04SU(18/23)E(A/J)*	Heating only indoor unit for the UK	0	---	---	0	---	---
EHVH08S(18/23)E(A/J)*	Heating only indoor unit	---	0	0	---	0	0
EHVX08S(18/23)E(A/J)*	Reversible indoor unit	---	0	0	---	0	0
EHVZ08S(18/23)E(A/J)*	(Integrated Bizone)	---	0	0	---	---	---
EHVH08SU(18/23)E(A/J)*	Heating only indoor unit for the UK	---	0	0	---	0	0

		ERGA04EAV37	ERGA04EAV3H	ERGA06EAV3H	ERGA08EAV3H	ERGA08EAV3H7
EHVH04S(18/23)E(A/J)*	Heating only indoor unit	0	0	---	---	---
EHVX04S(18/23)E(A/J)*	Reversible indoor unit	0	0	---	---	---
EHVZ04S(18/23)E(A/J)*	(Integrated Bizone)	---	0	---	---	---
EHVH04SU(18/23)E(A/J)*	Heating only indoor unit for the UK	---	0	---	---	---
EHVH08S(18/23)E(A/J)*	Heating only indoor unit	---	---	0	0	0
EHVX08S(18/23)E(A/J)*	Reversible indoor unit	---	---	0	0	0
EHVZ08S(18/23)E(A/J)*	(Integrated Bizone)	---	---	0	0	0
EHVH08SU(18/23)E(A/J)*	Heating only indoor unit for the UK	---	---	0	0	0

Kit availability

Reference	Description	EHV*(04/08)S*E(A/J)*						EHVH(04/08)SU*E(A/J)*	
EHVH*	Heating only indoor unit	---	18 - 6V	18 - 9W	---	23 - 6V	23 - 9W		
EHVX*	Reversible indoor unit	18 - 3V	18 - 6V	18 - 9W	23 - 3V	23 - 6V	23 - 9W		
EHVZ*	(Integrated Bizone)	---	18 - 6V	18 - 9W	---	23 - 6V	23 - 9W		
EHVH*U*	Heating only indoor unit for the UK							18 - 6V	23 - 6V
EKRP1HBAA	Digital I/O PCB	*(1) (2)	0	0	0	0	0	0	0
EKRP1AHTA	Demand PCB	*(3)	0	0	0	0	0	0	0
EKPCCAB4	PC cable	*(4)	0	0	0	0	0	0	0
KRCS01-1	Remote indoor sensor	*(5)	0	0	0	0	0	0	0
EKRSCA1	Remote sensor for outdoor	*(5)	0	0	0	0	0	0	0
EKHVTC	Corner pipe bend kit								
EKHVCONV4	Conversion kit: heating only to reversible.		0	0	0	0	0	0	0
EKUHWG3D	-G3- kit							0 (6)	0 (6)
BRP069A71	WLAN module	*(7)	0	0	0	0	0	0	0
BRC1HH*	HCI (Human Comfort Interface)		0	0	0	0	0	0	0
EKRELSG	Relay for Smart Grid								
FWXV10ATV3	Heat pump convector		0	0	0	0	0	0	0
FWXV15ATV3	Heat pump convector		0	0	0	0	0	0	0
FWXV20ATV3	Heat pump convector		0	0	0	0	0	0	0
EKRTWA	Wired room thermostat		0	0	0	0	0	0	0
EKRTR1	Wireless room thermostat		0	0	0	0	0	0	0
EKRTETS	External sensor room thermostat	*(8)	0	0	0	0	0	0	0

Reference	Description		
	Only applicable for -EHVH* & EHVX*- models	EHVH*	EHVX*
BZKA7V3	Bizone kit	0	0

Notes

- (1) PCB that provides additional output connections: - -
(a) Control external heat source (bivalent operation).
(b) Output remote ON/OFF signal space heating/cooling OR bottom plate heater -*KBPTH16* - control.
(c) Remote alarm output
- (2) Additional relays to allow bivalent control in combination with an external room thermostat are field-supplied.
- (3) PCB to receive up to 4 digital inputs for power limitation, only for -EHV(H/X/Z)(04/08)E(A/J)*-.
- (4) Data cable for connection with PC.
- (5) Only 1 remote sensor can be connected: indoor OR outdoor sensor.
- (6) This kit is mandatory for the UK models.
- (7) The WLAN cartridge is supplied in the accessory bag of the unit and is meant to be plugged into the SD card slot on the MMI-2. In case of bad signal reception, the WLAN cartridge can be removed and replaced by the WLAN module.
- (8) Can only be used in combination with wireless room thermostat -EKRTR1-.
- (9) The backup heater capacity depends on a user interface setting.

Remark

Other combinations than mentioned in this combination table are prohibited.

Factory-mounted equipment for -EHV(H/X/Z)08S*E(A/J)*-

Description	EHV(H/X/Z)08S*E(A/J)*			
Heating only model -EHVH*-	18 - 6V (9)	18 - 9W (9)	23 - 6V (9)	23 - 9W (9)
Reversible model -EHVX*-	18 - 6V (9)	18 - 9W (9)	23 - 6V (9)	23 - 9W (9)
(Integrated Bizone)	18 - 6V (9)	18 - 9W (9)	23 - 6V (9)	23 - 9W (9)
Heating only indoor unit for the UK	18 - 6V (9)		23 - 6V (9)	
Backup heater -3kW 1N~230 V-	-	-	-	-
Backup heater -2-4-6kW 1N~230 V-	0	-	0	-
Backup heater -2-4-6kW 3~230 V-	0	-	0	-
Backup heater -3-6-9kW 3N~400 V-	-	0	-	0
Domestic hot water tank -180L-	0	0	-	-
Domestic hot water tank -230L-	-	-	0	0