



Notes

- The ESP curves are the maximum ESP curves, with and without domestic hot water tank installed on top of the indoor unit (pump rpm: 4000). The pump of the indoor unit is inverter-controlled and functions to have a fixed ΔT between the return water temperature and the leaving water temperature.
- In case of installing a domestic hot water tank, there is an additional pressure drop over the 3-way valve (delivered as an accessory with the tank).

ESP: External Static Pressure
 Flow: water flow through the unit

Warning

- Selecting a flow outside the operating area can damage the unit or cause the unit to malfunction. See also the minimum and maximum allowed water flow range in the technical specifications.
- Water quality must be according to EU directive 98/83 EC.