




NOTES to go through before starting the unit

-  : Earth wiring
-  : Wire number 15
-  : Field supply
-  : Connection ** continues on page 12 column 2
-  : Several wiring possibilities
-  : Option
-  : Wiring depending on model
-  : Not mounted in switch box
-  : PCB

LEGEND

Part n°	Description	
A1P	main PCB	
E4H	booster heater	
F2B	#	overcurrent fuse booster heater
K3M	contactor booster heater	
M3S	3 way valve for floorheating / domestic hot water	
Q1DI	#	earth leakage circuit breaker
Q2L	thermal protector booster heater	
R5T	domestic hot water thermistor	
X*M	terminal strip	

- * : optional
- # : field supply