



III high speed

II medium speed

I low speed

ESP: external static pressure

Flow: waterflow through the unit

## NOTES

- 1 Selecting a flow outside the curves can cause damage to or malfunctioning of the unit. See also minimum and maximum allowed water flowrange in the technical specifications.
- 2 Water quality must be according to EN directive EC 98/83 EC