


EBLQ011-016BB6W1



- I: High speed
- II: medium speed

ESP: External static pressure
Flow: waterflow through the unit

Caution:
Selecting a flow outside the curves can cause damage to or malfunction of the unit. See also minimum and maximum allowed water flowrange in the technical specifications.