

Outdoor combination table for *HYHB*AAV3

		*VLQ05CAV3	*VLQ08CAV3
*HYHBH05AAV3	Heating only	○	---
*HYHBH08AAV3	Heating only	---	○
*HYHBX08AAV3	Reversible	---	○

Boiler combination table for *HYHB*AAV3

		*HYKOMB33AA
*HYHBH05AAV3	Heating only	○
*HYHBH08AAV3	Heating only	○
*HYHBX08AAV3	Reversible	○

Kit availability for outdoor units

		*VLQ05CAV3	*VLQ08CAV3
EKDP008CA	Drain pan kit	○	○
EKDPH008CA	Heater tape for drain pan	○	○
EKFT008CA	U-beams for outdoor	○	○

Kit availability for*HYHB*AAV3

Reference	Description	*HYHBH05AAV3	*HYHBH08AAV3	*HYHBX08AAV3
EKRSCA1 (1)	Remote sensor for outdoor	○	○	○
KRCSO1-1 (1)	Remote sensor for indoor	○	○	○
*KRUCBL1	User interface language group 1	○	○	○
*KRUCBL2	User interface language group 2	○	○	○
EKRP1HBAA (3)	Digital I/O PCB	○	○	○
KRP1AHTA (4)	Demand PCB	○	○	○
*KRTWA	Wired room thermostat option kit	○	○	○
*KRTR1	Wireless room thermostat option kit (incl. receiver)	○	○	○
*KRTEITS (5)	External temperature sensor option kit	○	○	○
(R)FVXXV15AVEB (6)	Heat pump convector	○	○	○
(R)FVXXV20AVEB (6)	Heat pump convector	○	○	○
*KVKHPC (6)	Valve kit heat pump convector	○	○	○
EKPCAB1 (7)	PC cable kit	○	○	○
EKPCAB2 (7)	PC cable kit	○	○	○
EKHYPD1	Drain pan kit	---	○	○
EKHWP300 (8)	Domestic hot water tank	○	○	○
EKHWP500 (8)	Domestic hot water tank	○	○	○

Kit availability for*HYKOMB33AA

Reference	Description	*HYKOMB33AA
EKH075787	Propane set	○
EKH090717	Concentric connection set 80/125	○
EKH093467	Cover plate for 33 class	○
EKH090707	Eccentric connection set	○

Notes

Remarks: Other combinations than mentioned in this combination table are prohibited

- (1) Only 1 sensor can be connected: indoor OR outdoor sensor
- (2) Possibility for DHW pre-heating by the heat pump, for Rotex brand the sanicube is available
- (3) PCB that provides additional output connections:
 - (a) Control external heat source (bivalent operation)
 - (b) Output remote ON/OFF signal space heating/cooling
 - (c) Remote alarm output
 - (d) Solar pump connection.
- (4) PCB to receive up to 4 digital inputs for power limitation
- (5) Can only be used in combination with the wireless room thermostat *KRTR1
- (6) Valve kit mandatory if heat pump convector is installed on reversible model (not mandatory for heating only model)
- (7) Data cable for connection with PC
- (8) Connection kit EKEPHT3H must be used for connection of tank.