

**ERLQ011-016BV3**




*RLQ units include special equipment (insulation heater sheet, ...) to ensure good operation in areas where low ambient temperature can occur together with high humidity conditions. In such conditions the *RHQ models may experience problems with severe ice build up on the aircooled coil. In case such conditions are expected, the *RLQ must be installed instead. These models contain countermeasures (insulation, heater sheet, ...) to prevent freeze up.

