

EPGA011-016DV

Factory-mounted equipment for EAV(H/X/Z)16S*DA*

Description	EAV(H/X/Z)16S*DA*			
Heating only model EAVH*	18 - 6V (8)	18 - 9W (8)	23 - 6V (8)	23 - 9W (8)
Reversible model EAVX*	18 - 6V (8)	18 - 9W (8)	23 - 6V (8)	23 - 9W (8)
(Integrated Bizone)	18 - 6V (8)	18 - 9W (8)	23 - 6V (8)	23 - 9W (8)
Backup heater 2-4-6kW 1N~230 V	0	-	0	-
Backup heater 2-4-6kW 3~230 V	0	-	0	-
Backup heater 3-6-9kW 3N~400 V	-	0	-	0
Domestic hot water tank 180L	0	0	-	-
Domestic hot water tank 230L	-	-	0	0

Outdoor combination table for EAV(H/X/Z)16S(18/23)DA

		EPGA11DAV3	EPGA14DAV3	EPGA16DAV3
EAVH16S(18/23)DA*	Heating only indoor unit	0	0	0
EAVX16S(18/23)DA*	Reversible indoor unit	0	0	0
EAVZ16S(18/23)DA*	(Integrated Bizone)	0	0	0

Kit availability for indoor units

Reference	Description	EAV*16S*DA*			
EAVH*	Heating only indoor unit	18 - 6V	18 - 9W	23 - 6V	23 - 9W
EAVX*	Reversible indoor unit	18 - 6V	18 - 9W	23 - 6V	23 - 9W
EAVZ*	(Integrated Bizone)	18 - 6V	18 - 9W	23 - 6V	23 - 9W
EKR1HBAA	Digital I/O PCB	0	0	0	0
EKR1AHTA	Demand PCB	0	0	0	0
BRC1HHDA	Simplified user interface	0	0	0	0
EKPCCAB4	PC cable	0	0	0	0
KRCS01-1	Remote indoor sensor	0	0	0	0
EKRSCA1	Remote sensor for outdoor	0	0	0	0
BRP069A61	LAN adapter for smartphone control	0	0	0	0
BRP069A62	LAN adapter for smartphone control	0	0	0	0
EKCC8-W	Universal centralised user interface	0	0	0	0
EKHVCONV2	Conversion kit: heating only to reversible.	0	0	0	0
FWXV15AVEB	Heat pump convector	0	0	0	0
FWXV20AVEB	Heat pump convector	0	0	0	0
EKVKHPC	Heat pump convector valve kit	0	0	0	0
EKR1TWA	Wired room thermostat	0	0	0	0
EKR1TR1	Wireless room thermostat	0	0	0	0
EKR1TETS	External sensor room thermostat	0	0	0	0

Kit availability for outdoor units

		EPGA11DAV3	EPGA14DAV3	EPGA16DAV3
EKBPH140L7	Bottom plate heater	0	0	0

Reference	Description		
	Only applicable for EAVH* & EAVX* models	EAVH*	EAVX*
BZKA7V3	Bizone kit	0	0

Notes

- (1) PCB that provides additional output connections:

(a) Control external heat source (bivalent operation).

(b) Output remote ON/OFF signal space heating/cooling

(c) Remote alarm output
- (2) Additional relays to allow bivalent control in combination with an external room thermostat are field-supplied.
- (3) PCB to receive up to 4 digital inputs for power limitation
- (4) Data cable for connection with PC.
- (5) Only 1 remote sensor can be connected: indoor OR outdoor sensor.
- (6) The valve kit is mandatory if a heat pump convector is installed on a reversible model (not mandatory for heating only models).
- (7) EKRTETS can only be used in combination with EKTR1
- (8) The backup heater capacity depends on a user interface setting.

Remark

Other combinations than mentioned in this combination table are prohibited.