




ERLA11-14DV3
ERLA11-14DW1
ERLA-DV37
ERLA-DW17



- | | |
|--|------------------------------------|
| ① Liquid stop valve with service port | ⑬ Service port ·5/16"· flare |
| ② Filter | ⑭ 4-way valve |
| ③ Rectifier | ⑮ R3T - Thermistor (suction) |
| ④ Economiser | ⑯ Accumulator |
| ⑤ Heat sink | |
| ⑥ Electronic expansion valve (main) | ⑰ Low pressure switch |
| ⑦ Electronic expansion valve (injection) | ⑱ R2T - Thermistor (discharge) |
| ⑧ R4T - Thermistor (heat exchanger) | ⑳ High pressure switch |
| ⑨ Distributor | ㉑ Muffler |
| ⑩ Heat exchanger | ㉒ Pressure sensor |
| ⑪ R5T - Thermistor (heat exchanger middle) | ㉓ Gas stop valve with service port |
| ⑫ R1T - Outdoor air | |