




ETV*DA* + ETS*DA*

ETB*DA*



Legend

Backup heater only operation
No outdoor unit operation

Outdoor unit operation if setpoint ≥ -20 °C

Pull-down area

Outdoor unit operation if setpoint > 55 °C and ΔT = -10 °C (ΔT = outlet temperature - inlet temperature)

In case valve kit 'AFVALVE1' is part of the system, then the minimum setpoint is -7 °C.

Remark

In restricted power supply mode, the outdoor unit, booster heater and backup heater can only operate separately.