

Indoor unit Field installed

Space heating/cooling - Water IN (screw connection, 1")

DHW - Cold Water IN (screw connection, 1") DHW - Hot water OUT (screw connection, 1") Water IN from outdoor unit (screw connection, 1")

Water OUT to outdoor unit (screw connection, 1")

Space heating/cooling - Water OUT (screw connection, 1")

Water IN from bivalent heat source (screw connection, 1")

Water OUT to bivalent heat source (screw connection, 1")

Optional Referigerant side

Pump

Backup heater

Expansion vessel Drain valve Safety valve

External thread 1" External thread 3/4"

Flow sensor

Tank valve

Bypass valve

Flow switch Screw connection Flare connection Quick coupling **Brazed connection**

Thermistor (water IN)

Thermistor (tank - water OUT)

Thermistor (tank)

Shut-off valve, female-female 1"

Space heating water pressure sensor

Thermistor (backup heater - water OUT)

C

a1

a2

c1

c2

d2

e

k

m B2L

B1PW

M1S

M2S

R1T

R2T

R7T

S1L

R5T, R8T

ETSH16E7