



ETSH16E7
ETSHB16E7
ETSX16E7
ETSB16E7



- Notes
1. Selecting a flow outside the operating area can damage the unit or cause the unit to malfunction.
See also the minimum and maximum allowed water flow range in the technical specifications.
 2. Water quality must be according to EU directive 2020/2184



- Notes
1. Selecting a flow outside the operating area can damage the unit or cause the unit to malfunction.
See also the minimum and maximum allowed water flow range in the technical specifications.
 2. Water quality must be according to EU directive 2020/2184