

EBBH-D6V
EBBH-D9W
EBBX-D6V
EBBX-D9W

- ① Space heating - water OUT
- ② Space heating - water IN
- ③ Shut-off valve
- ④ Magnetic filter / dirt separator
- ⑤ Safety valve
- ⑥ Air purge
- ⑦ Drain valve
- ⑧ Flow sensor
- ⑨ Plate heat exchanger
- ⑩ Expansion vessel
- ⑪ Backup heater

- ⑫ Pump
- ⑬ Space heating water pressure sensor
- ⑭ R1T - Outlet water heat exchanger thermistor
- ⑮ R2T - Outlet water backup heater thermistor
- ⑯ R3T - Thermistor (heat exchanger, liquid pipe)
- ⑰ R4T - Inlet water thermistor

