




EBV* + EBB* + EBS*



Notes

1. Tank preheating
For details, see the installer reference guide.
2. In restricted power supply mode, the outdoor unit and backup heater can only operate separately.