





EPBX10A4V / EPBX10A9W
EPBX14A4V / EPBX14A9W

SWB1



SWB1



In the case the grid power has no Neutral an additional adapter needs to be used.
EKBUKRW1 - EKBUKRW3

