










Protective zone in front of a building	
Floor-standing	Elevated
	
Protective zone for right corner installation	
Floor-standing	Elevated
	
	

Protective zone for left corner installation	
Floor-standing	Elevated
	

Protective zone for on-roof installation


- Requirements for the protective zones:
- 1.No openings into habitable areas of the building.
 - 2.No ignition sources (neither permanently nor for a short period of time).
 - 3.The protective zone must not extend to adjacent buildings or public traffic areas.
 - 4.Other units may only be installed in your unit's protective zone if they are of the same type.
 - 5.No ventilation or skylight openings allowed in the protective zone (on-roof installation).