



X42M Ports	Description	Max. No of wires per position
1	HV Smart Grid 1 - L (230 VAC)	1
2	HV Smart Grid 1 - N (230 VAC)	1
3	HV Smart Grid 2 - L (230 VAC)	1
4	HV Smart Grid 2 - N (230 VAC)	1
5		
6		
7	Power Distribution Installer - L (230 VAC)	2
8	Power Distribution Installer - L (230 VAC)	2
9	Power Distribution Installer - N (230 VAC)	2
10	Power Distribution Installer - N (230 VAC)	2
11	Spare 230 VAC Output Pump (NO)	1
12	Spare 230 VAC Output Pump (N)	1
13	Spare 230 VAC Output 1 (NO)	1
14	Spare 230 VAC Output 1 (N)	1
15	Spare 230 VAC Output 2 (NO)	1
16	Spare 230 VAC Output 2 (N)	1

X43M Ports	Description	Max. No of wires per position
1	Input 1 Room Thermostat 1 (Voltage Free)	1
2	Input 2 Room Thermostat 1 (Voltage Free)	1
3	L Room Thermostat (1 & 2)	2
4	N Room Thermostat (1 & 2)	2
5	Input 1 Room Thermostat 2 (Voltage Free)	1
6	Input 2 Room Thermostat 2 (Voltage Free)	1
7	Spare Dry Contact Free Potential 1 - COM	1
8	Spare Dry Contact Free Potential 1 - NO	1
9	Spare Dry Contact Free Potential 1 - NC	1
10	Spare Dry Contact Free Potential 2 - COM	1
11	Spare Dry Contact Free Potential 2 - NO	1
12	Spare Dry Contact Free Potential 2 - NC	1
13	Spare 230 VAC Output 3 (NO)	1
14	Spare 230 VAC Output 3 (N)	1
15	Spare 230 VAC Output 4 (NO)	1
16	Spare 230 VAC Output 4 (N)	1

**NOTES**

- For Ports 1-2 and 5-6: Only ON/OFF voltage free contacts.
- Terminal combinations can only be used for one option.