


EPVX07A
EPVX07UA

	Screw connection		Brazed connection
	Quick coupling		Flare connection



Field piping connections

- 21 Water in connection ·1"·
- 22 Water out connection ·1"·
- 23 Screw connection ·1"·
- 24 R11T - Tank thermistor
- 25 Shut-off valve normally closed ··
- 26 Hose for air purge
- 27 Drain hose for water
- 28 Quick connection
- 29 Shut-off valve ·1"-1"· (male-female)

- 1 Space heating - water OUT
- 2 Space heating - water IN
- 3 Domestic hot water: hot water out ·3/4"·
- 4 Domestic hot water: cold water in ·3/4"·
- 5 Recirculation connection ·3/4"· (female)
- 6 Expansion vessel
- 7 Magnetic filter / dirt separator
- 8 Safety valve
- 9 Air purge
- 10 Gas separator
- 11 Pump
- 12 Sensor
- 13 Space heating water pressure sensor
- 14 Flow sensor
- 15 Backup heater
- 16 3-way valve (space heating/domestic hot water)
- 17 R1T - Inlet water thermistor
- 18 R2T - Outlet water backup heater thermistor
- 19 R5T - Tank thermistor
- 20 R8T - Tank thermistor