


EZESH20AUAW1B



- Analogic input**
- TDIS1** Discharge temperature sensor
 - TDIS2** Discharge temperature sensor backup
 - TCOND OUT** Condenser outlet temperature sensor
 - TSUC** Suction gas temperature
 - TECO OUT** Economiser outlet temperature sensor
 - TAMB** Outside air temperature sensor (in condensor)
 - TE_A_IN1** Inside air temperature sensor (in evaporator)
 - TE_A_IN2** Inside air temperature sensor backup (in evaporator)
 - TE_A_OUT1** Inside air temperature sensor (out evaporator)
 - TE_A_OUT2** Inside air temperature sensor backup (out evaporator)
 - TDTS** Defrost temperature sensor
 - PSUC** Low pressure sensor
 - PDIS** High pressure sensor
 - CND1-2** Condenser heat exchanger 1 and 2
- Digital input**
- HPS** High pressure switch
 - DPS** Air differential pressure switch
 - HTT** Heater stop thermostat
- Solenoid valve**
- COMP BSV** Compressor bypass solenoid valve [NC]
 - COND CPS** Condenser partialisation solenoid valve [NO]
- Expansion valve**
- MAIN EV** Electronic expansion valve main
 - INJ EV** Expansion valve (injection)

