

# FWN-AT/AF

	<b>FWN</b>	<b>04</b>	<b>05</b>	<b>06</b>	<b>07</b>	<b>08</b>	<b>10</b>
Electric heater (*)	EDEH(S)(B)A6	EDEH04A6		EDEH(S)(B)06A6		EDEH(S)(B)A10A6	
2-pipes 230V ON-OFF 3 way valve	ED2MV_A6	ED2MV04A6			ED2MV10A6		
4-pipes 230V ON-OFF 3 way valve	ED4MV_A6	ED4MV04A6			ED4MV10A6		
Motorised fresh air intake louvers	EDMFA_A6	EDMFA04A6		EDMFA06A6		EDMFA10A6	
Auxiliary drain pan (vertical models)	EDDPV_A6			EDDPV10A6			
Auxiliary drain pan (horizontal models)	EDDPV_A6			EDDPH10A7			
Controller - Advanced Plus version	FWEC3A			FWEC3A			
Split controller - power control board	FWECSAP			FWECSAP			
Split controller - control panel	FWECSAC			FWECSAC			
Controller temperature sensor kit	FWTSKA			FWTSKA			
Controller relative humidity sensor kit	FWHSKA			FWHSKA			
Controller wall mounting kit	FWFCKA			FWFCKA			

(\*) Requires electronic controller