Discharge		FXSN50 A2VEB	FXSN71 A2VEB	FXSN112 A2VEB
Description	Option kit			
Air discharge adaptor for round ducts	KDAP25A56A	X		
	KDAP25A71A		X	
	KDAP25A140A			X
Multi zoning kit	"AZER6DAIST07S2(3)(4)/ AZEZ6DAIST07S2(3)(4)"	X		
	"AZER6DAIST07M4(5)(6)/ AZEZ6DAIST07M4(5)(6)"		X	
	"AZER6DAIST07L5(6)(7)(8)/ AZEZ6DAIST07L5(6)(7)(8)"			X

Operation control		FXSN50 A2VEB	FXSN71 A2VEB	FXSN112 A2VEB
Description	Option kit			
Wired remote control	BRC1H52K	X	X	X
	BRC1H52S	X	X	X
	BRC1H52W	X	X	X
Central remote control	DCS302CA51	X	X	X
Unified ON/OFF controller	DCS301BA51	X	X	X
Intelligent touch controller	DCS601C51	X	X	X
Schedule timer	DST301BA51	X	X	X
Wiring adaptor for electrical appendices	KRP4A52	X(*3,4)	X(*3,4)	X(*3,4)
Wiring adaptor for electrical appendices	KRP4A51	X(*3,4)	X(*3,4)	X(*3,4)
Optional PCB for external electric heaters, humidifiers and/or hour meters	EKRP1B2A	X(*1,2,3,4)	X(*1,2,3,4)	X(*1,2,3,4)
Wireless remote control H/P	BRC4C65	X	X	X
Wireless remote control C/O	BRC4C66	X	X	X
Simplified remote control for hotel use	BRC2E52C7	X(*6)	X(*6)	X(*6)
Remote control for hotel use	BRC3E52C7	X(*6)	X(*6)	X(*6)
Remote sensor	KRCS01-6B	X	X	X
Electrical box with earth terminal (3 blocks)	KJB311A	X	X	X
Electrical box with earth terminal (2 blocks)	KJB212A	X	X	X
Electrical box with earth terminal	KJB411A	X	X	X
External adaptor for outdoor unit (installation on indoor unit)	DTA104A61	X(*3,4)	X(*3,4)	X(*3,4)
PCB for multi-tenant indoor units	DTA114A61	X(*3,4,7)	X(*3,4,7)	X(*3,4,7)
Installation box for adaptor PCB	KRP1BA101	X	X	X
	KRP1B101	X	X	X
Digital input adaptor	BRP7A51	X(*3,4,5)	X(*3,4,5)	X(*3,4,5)
iTouch Manager	DCM601A51	X	X	X
Wireless room thermostat	K.RSS	X	X	X

NOTES

(*1) Electric heaters and humidifiers are field-supplied. Do not install them inside the equipment (refer to installation manual ·EKRP1B2A·).
(*2) When installing electric heaters, an optional PCB for external electric heaters (·EKRP1B2·) is required for each indoor unit
(*3) Maximally ·2· optional PCBs can be mounted.
(*4) This option needs to be installed together with installation box ·KRP1B101/KRP1BA101·.
(*5) Only possible in combination with remote control ·BRC2/3E52C7, BRC1H52K/S/W
(*6) Included languages are:
Language pack 1: English, German, French, Dutch, Spanish, Italian, and Portuguese.
With PC cable EKPCCAB3 in combination with the Updater PC software, you can additionally change the language to:
Language pack 2: English, Bulgarian, Croatian, Czech, Hungarian, Romanian, and Slovenian.
Language pack 3: English, Greek, Polish, Russian, Serbian, Slovak, and Turkish.
(*7) This option is not available when CO2 leak detection is enabled.