



Dimensioni - Dimensions - Dimensions
Abmessungen - Dimensiones

BSB0870Y1ACA




Schema di montaggio - Mounting scheme - Schema de montage
Montageschema - Esquema de montaje



- * Raccomandazioni in sede di installazione e per il controllo fornite sul manuale di installazione
- * To be advised at time of order for factory installation and operating instructions
- * Recommendations au moments d'installations et pour le contrôle fournis sur le manuel d'installation
- * Empfehlungen für die Installationsphase und zur Kontrolle, die im Handbuch zur Installation enthalten sind
- * Por cuanto respecta a recomendaciones de instalación y control ver manual de instalación

Massa e misure imballi - Packing mass and dimensions - Masse et dimensions emballages
Verpackungsmasse und-abmessungen - Masa y medidas del embalaje





MULTI-CIRCUIT UNITS
When using one or more multi-circuit units in the same cold room it is necessary to order separately the suitable cable kit (1 time only even if the units are more than one)

UNIT 1 - Master

UNIT 8 (max) - Slave

CABLE KIT

AIR COOLED UNITS (model MSB3370 - MSB5820 - BSB2650)

LT COLD ROOM 1 x 1KIT629ACC (Remote control panel - Ethernet connection - Door microswitch - Door heater)

NT COLD ROOM 1 x 1KIT572ACC (Remote control panel - Ethernet connection - Door microswitch)

WATER COOLED UNITS (model BSB1710)

LT COLD ROOM 1 x 1KIT629ACC (Remote control panel - Ethernet connection - Door microswitch - Door heater)

WATER COOLED UNITS (model MSB2181 - MSB3371 - MSB5821 - BSB2651)

LT COLD ROOM 1 x 1KIT572ACC (Remote control panel - Ethernet connection - Door microswitch)

NT COLD ROOM