AVA125A

This unit has to be fixed with fixing screws as shown below. In case of fixing it at the bottom Pull-out direction of air filter In case vibration resistance is required, fix it at both the bottom and the rear. Fixture for preventing overturning Suction grille stopper 330 Accessory 600 350 0.7 Dimension of air filter when pulled out 2-7 x 15mm oblong holes 677 (2) Required installation space (8) ± 46 44 Position of fully opened suction grille **(6)** 49 **(6)** 130 95 90 200 190 9 130_ 75 223 260 34 190 266 253 322 266 598 260 Item Part name Remark 4 holes for anchor bolts 130 215 1 Air suction grille Ø14 2 Air filter 3 Hole for piping 70 x 90mm oblong holes 4 Hole for piping Knockout hole for recirculation piping or wiring of optional equipment Ø80 5 Hole for piping Knockout hole for recirculation piping or wiring of optional equipment Ø27 6 Piping hole (rear) 80 x 130mm oblong holes 7 Piping hole (bottom) 126 x 130mm oblong holes 8 Liquid pipe Ø9.5 flared connection Ø15.9 flared connection 9 Gas pipe **VIEW B** 10 Drain pipe connection VP20

Notes

The unit nameplate is located on the switch box cover, inside the suction grille.