


## Installation service space

The measure of these values is "mm".


### (A) When there are obstacles on suction sides.

● **No obstacle above**


- ① Stand-alone installation
  - Obstacle on the suction side only



- Obstacle on both sides and suction side, too




- ② Series installation (2 or more) (Note 1)
  - Obstacle on the suction side and both sides




● **Obstacle above, too.**


- ① Stand-alone installation
  - Obstacle on the suction side, too



- Obstacle on both sides and suction side, too




- ② Series installation (2 or more) (Note 1)
  - Obstacle on the suction side and both sides




### (B) When there are obstacles on discharge sides.

● **No obstacle above**

- ① Stand-alone installation
  - Obstacle on the discharge side only




- ② Series installation (2 or more) (Note 1)
  - Obstacle on the discharge side only




● **Obstacle above, too**

- ① Stand-alone installation
  - Obstacle on the discharge side only, too



- ② Series installation (2 or more) (Note 1)
  - Obstacle on the discharge side




### (C) When there are obstacles on both suction and discharge sides.:

Pattern 1

When the obstacles on the discharge side is higher than the unit. (L>H)  
(There is no limit for the height of obstructions on the suction side.)

● **No obstacle above**

- ① Stand-alone installation
  - No obstacle above



- ② Series installation (2 or more) (Note 1)
  - No obstacle above

