## FDQ-B

## Operation control

-				
No.	Type			FDQ200/250B
1	Remote control	Wired		BRC1D52 / BRC1E52A7 (*4) / BRC1E52B7 (*5)
		Infrared	H/P	BRC4C65
			C/O	BRC4C66
2	Simplified remote control (with operation mode selector button)			BRC2E52C7 (*7)
3	Simplified remote control (without operation mode selector button)			BRC3E52C7 (*7)
4	Optional PCB for external electric heaters, humidifiers and/or hour meters			EKRP1B2A (*1) (*2) (*3)
5	Adapter for wiring (interlock for fresh air intake fan)			KRP1B54 (*3)
6	Wiring adapter for electrical appendices			KRP4A51 (*3)
7	Remote sensor			KRCS01-4B
8	Central remote control			DCS302C51
9	Unified ON/OFF controller			DCS301B51
10	Schedule timer			DST301B51
11	Remote "ON/OFF" and "forced OFF" kit			EKRORO
12	Mounting plate for adapter PCB			KRP4A96
13	Interface adapter for the Sky Air series			DTA112B51
14	Digital input adapter			BRP7A54 (*3) (*6)

## NOTES

- 1. Electric heaters and humidifiers are field-supplied. Do not install them inside the equipment (refer to installation manual EKRP1B2A).
- 2. When installing electric heaters, an optional PCB for external electric heaters (EKRP1B2A) is required for each indoor unit.
- 3. These options require mounting plate KRP4A96.
  - Maximally 2 optional PCBs can be mounted.
- 4. Included languages are: English, German, French, Dutch, Spanish, Italian, Greek, Portuguese, Russian, Turkish and Polish.
- 5. Included languages are: English, German, Albanian, Bulgarian, Croatian, Czech, Hungarian, Romanian, Serbian, Slovak and Slovenian.
- 6. Only possible in combination with simplified remote control BRC2/3E52C7.
- 7. Included languages are:
  - Language pack 1: English, German, French, Dutch, Spanish, Italian and Portuguese.
  - With PC cable EKPCCAB3 in combination with the Updater PC software, you can additionally change the language to:
  - Language pack 2: English, Bulgarian, Croatian, Czech, Hungarian, Romanian and Slovenian.
  - Language pack 3: English, Greek, Polish, Russian, Serbian, Slovak and Turkish.