

Cooling



- (1) Operation range
- 2 Pull-down operation range
- 3 Warm-up operation range





Notes

- 1. Depending on operation and installation conditions, the indoor unit can change over to freeze-up operation (indoor de-icing).
- 2. To reduce the freeze-up operation (indoor de-icing) frequency, it is recommended to install the outdoor unit in a location not exposed to wind.
- 3. If the unit is selected to operate at ambient temperature < --5°C· for ·3· days or more, with relative humidity of 100%, it is required to install the optional bottom plate heater.