

Notes

- 1 The operation noise measuring method is in accordance with JISC9612.
- 2 Operating conditions: power source 220-240 V/220 V 50/60 Hz; JIS standard
- 3 Operating noise varies depending on operation and ambient conditions.
- 4 Background noise already taken into account.
- 5 Measuring location: anechoic chamber

90

80

70

60

50

40

30

20

NR80

NR70

NR65

NR55

NR45

NR40