

Notes

- 1. The capacities are based on the following conditions:
Corresponding refrigerant piping length: ·5· m
Level difference: ·0·m
- 2. The bold cells indicate the standard conditions.
- 3. The heating capacity does not include the capacity drop that occurs during a frosting period and defrost operation.
- 4. The values above are for connecting with the following indoor unit types:
·1.5, 2.0, 2.5, 3.5, 4.2, 5.0, 6.0· kW class
 - * For ·FTXM-R, FTXM-A, FTXA-CW, FTXA-CS, FTXA-CB, FTXA-DG, FTXA-DP, FTXA-DL, FTXA-DC, FTXA-DY· units onlyWall-mounted ·CTXA-AS, CTXA-AT, CTXA-AW, CTXA-BB, CTXA-BS, CTXA-BT, CTXA-CW, CTXA-CB, CTXA-CS, CTXA-DG, CTXA-DP, CTXA-DL, CTXA-DC, CTXA-DY, CTXM-A, CTXM-M, CTXM-N, CTXM-R, FTXA-AS, FTXA-AT, FTXA-AW, FTXA-BB, FTXA-BS, FTXA-BT, FTXA-CW, FTXA-CB, FTXA-CS, FTXA-DG, FTXA-DP, FTXA-DL, FTXA-DC, FTXA-DY, FTXM-A, FTXM-M, FTXM-N, FTXM-R, FTXJ-AB, FTXJ-AS, FTXJ-AW, FTXJ-AW9, FTXJ-AB9, FTXJ-AS9· series