

4MXM68A8

50Hz 230V calefacción

①	②	Temperatura de aire interior [°C DB]											
		16°C		18°C		20°C		21°C		22°C		24°C	
		TC	PI	TC	PI	TC	PI	TC	PI	TC	PI	TC	PI
		kW	kW	kW	kW	kW	kW	kW	kW	kW	kW	kW	kW
2.0+2.5+2.5+3.5	-20.0	5.18	1.85	5.05	1.87	4.89	1.91	4.83	1.91	4.76	1.92	4.61	1.94
	-15.0	6.38	1.96	6.24	1.98	6.09	2.01	6.02	2.02	5.95	2.03	5.80	2.05
	-10.0	7.58	2.07	7.43	2.09	7.29	2.11	7.21	2.13	7.14	2.14	6.99	2.16
	-5.0	8.77	2.17	8.63	2.20	8.48	2.22	8.41	2.23	8.34	2.25	8.19	2.27
	0.0	9.97	2.28	9.82	2.31	9.68	2.33	9.60	2.34	9.53	2.35	9.38	2.38
	6.0	11.40	2.41	11.26	2.44	11.11	2.46	11.04	2.47	10.96	2.48	10.82	2.51
	10.0	12.36	2.50	12.21	2.52	12.07	2.55	11.99	2.56	11.92	2.57	11.77	2.59
	15.0	13.55	2.61	13.41	2.63	13.26	2.65	13.19	2.67	13.11	2.68	12.97	2.70
2.5+2.5+2.5+2.5	-20.0	5.29	1.77	5.15	1.81	4.99	1.82	4.93	1.83	4.86	1.84	4.72	1.88
	-15.0	6.46	1.88	6.32	1.91	6.17	1.93	6.10	1.94	6.03	1.95	5.89	1.98
	-10.0	7.63	1.99	7.49	2.01	7.35	2.04	7.27	2.05	7.20	2.06	7.06	2.08
	-5.0	8.81	2.10	8.66	2.12	8.52	2.14	8.45	2.16	8.38	2.17	8.23	2.19
	0.0	9.98	2.20	9.84	2.23	9.69	2.25	9.62	2.26	9.55	2.27	9.41	2.30
	6.0	11.39	2.33	11.24	2.36	11.10	2.38	11.03	2.39	10.96	2.40	10.81	2.43
	10.0	12.33	2.42	12.18	2.44	12.04	2.47	11.97	2.48	11.90	2.49	11.75	2.51
	15.0	13.50	2.53	13.36	2.55	13.21	2.57	13.14	2.59	13.07	2.60	12.92	2.62
2.5+2.5+2.5+3.5	-20.0	5.30	1.76	5.16	1.78	5.00	1.82	4.94	1.82	4.87	1.83	4.73	1.85
	-15.0	6.47	1.87	6.33	1.89	6.18	1.92	6.11	1.93	6.04	1.94	5.90	1.96
	-10.0	7.64	1.98	7.50	2.00	7.36	2.02	7.28	2.04	7.21	2.05	7.07	2.07
	-5.0	8.82	2.08	8.67	2.11	8.53	2.13	8.46	2.14	8.39	2.16	8.24	2.18
	0.0	9.99	2.19	9.85	2.22	9.70	2.24	9.63	2.25	9.56	2.26	9.42	2.29
	6.0	11.40	2.32	11.26	2.35	11.11	2.37	11.04	2.38	10.96	2.39	10.82	2.42
	10.0	12.36	2.41	12.21	2.43	12.07	2.46	11.99	2.47	11.92	2.48	11.77	2.50
	15.0	13.55	2.52	13.41	2.54	13.26	2.56	13.19	2.58	13.11	2.59	12.97	2.61

Símbolos

TC: Capacidad total [kW]

PI: Consumo [kW]

① Combinaciones de unidades interiores

② Temperatura del aire exterior [°C BH]